


Warning: It is a requirement to check  
airstrip condition and details with owner

# Lake Everard Station, SA



NORTH TO THE TOP - DRAWING NOT TO SCALE

<b>Elevation:</b>	460 Feet AMSL	<b>Time Zone:</b>	UTC + 9.5
<b>GPS Position:</b>	31° 44' 35" South 135° 10' 28" East	<b>Area Briefing:</b>	53
<b>WAC Chart:</b>	Tarcoola (3354)	<b>ALA Code:</b>	YLVD
<b>Owner/Operator:</b>	Lake Everard Station (08) 86481884, <a href="mailto:michaeloneil606@gmail.com">michaeloneil606@gmail.com</a>		
<b>Strip Directions:</b>	11-29		
<b>Strip Lengths:</b>	1200 M		
<b>Strip Surface:</b>	Unsealed - dirt		
<b>Windsock:</b>	Yes		
<b>Strip Markers:</b>	White tyres		
<b>Lighting:</b>	Nil		
<b>Fuel:</b>	Nil		
<b>Procedures And Remarks:</b>	CTAF 126.7. Melbourne Centre 123.5 (3000 feet). HF 3461/6565/8822. The runway is kept maintained for use by the RFDS. Caution: two roads cross the runway, beware of vehicles. Permission required prior to use.		