


Warning: It is a requirement to check
airstrip condition and details with owner

Crab Claw Island, NT



Elevation:		33 Feet AMSL		Time Zone:		UTC + 9.5	
GPS Position:		12° 42' 48" South 130° 37' 22" East		Area Briefing:		80	
WAC Chart:		Darwin (3109)					
Owner/Operator:		Crab Claw Island Resort (08) 89782313, reservations@crabclaw.com.au					
Strip Directions:		16-34					
Strip Lengths:		830 M					
Strip Surface:		Unsealed - dirt					
Windsock:		Nil					
Strip Markers:		Nil					
Lighting:		Nil					
Fuel:		Nil					
Procedures And Remarks:		Brisbane Centre 118.15 (in the circuit). HF 3452/6541/8843. Beware of trees close to the runway. This airstrip is used by resort guests and for the occasional Aero Club fly in. It has good drainage but is not all weather.					