


Warning: It is a requirement to check airstrip condition and details with owner prior to use

# Yantabangee Station, NSW



<b>Elevation:</b>	340 Feet AMSL	<b>Time Zone:</b>	UTC + 10
<b>GPS Position:</b>	30° 34.505' South 143° 37.123' East	<b>Area Briefing:</b>	22
<b>WAC Chart:</b>	Broken Hill (3355)		
<b>Owner/Operator:</b>	Yantabangee Station 0427 689764 (mobile), <a href="mailto:ray.dennis@lightforce.com.au">ray.dennis@lightforce.com.au</a>		
<b>Strip Directions:</b>	01-19	04-22	
<b>Strip Lengths:</b>	1100 M	700 M	
<b>Strip Surface:</b>	Unsealed - ironstone		
<b>Windsock:</b>	Nil		
<b>Strip Markers:</b>	Nil		
<b>Lighting:</b>	Nil		
<b>Fuel:</b>	Nil		
<b>Procedures And Remarks:</b>	Melbourne Centre 124.9 (2500 feet). HF 3461/6565/8822. UHF channel 39. Latest information: Ray Dennis 0427 689764 (mobile). Permission required prior to use.		