


Warning: It is a requirement to check
airstrip condition and details with owner

Beverley, WA



NORTH TO THE TOP - DRAWING NOT TO SCALE

Elevation:	690 Feet AMSL	Time Zone:	UTC + 8
GPS Position:	32° 07.524' South 116° 56.977' East	Area Briefing:	60
WAC Chart:	Albany (3462)	ALA Code:	YBEV
Owner/Operator:	Beverley Shire (08) 96461200, admin@beverley.wa.gov.au		
Strip Directions:	08-26	16-34	
Strip Lengths:	700 M	1460 M	
Strip Surface:	Gravel, with some sealed sections		
Windsock:	Yes		
Strip Markers:	Plough discs		
Lighting:	Nil		
Fuel:	Avgas - emergency supply only		
Procedures And Remarks:	CTAF 126.85. Melbourne Centre 120.3 (in the circuit). HF 3461/6565/8822. The runway 08 threshold becomes boggy after rain, a cross and cones are used to indicate when threshold is displaced. Right hand circuits runway 34, please turn as soon as possible to avoid overflying the township. Beware of crosswind and turbulence from trees. Caution: gliders making right circuits runway 34 (listening on 126.7). Intensive gliding operations in progress on Fridays, Saturdays, Sundays and long weekends. Rifle firing in progress is indicated by red flag on northern side runway 08, do not use RWY 08-26 on Saturday afternoons. Latest information on airfield number (08) 96460320 (weekends only). Cross check details with ERSA.		