


Warning: It is a requirement to check
airstrip condition and details with owner

Beverley, WA



Elevation:	690 Feet AMSL	Time Zone:	UTC + 8
GPS Position:	32° 07' 31" South 116° 56' 59" East	Area Briefing:	60
WAC Chart:	Albany (3462)	ALA Code:	YBEV
Owner/Operator:	Beverley Shire (08) 96461200, admin@beverley.wa.gov.au		
Strip Directions:	08-26	16-34	
Strip Lengths:	900 M	1460 M	
Strip Surface:	Gravel, with some sealed sections		
Windsock:	Yes		
Strip Markers:	Plough discs		
Lighting:	Nil		
Fuel:	Avgas - not for sale, emergency supply only		
Procedures And Remarks:	CTAF 126.85. Melbourne Centre 120.3 (in the circuit). HF 3461/6565/8822. Animal hazard exists. The runway 08 threshold becomes boggy after rain, a cross and cones are used to indicate when threshold is displaced. Right hand circuits runway 34, please turn as soon as possible to avoid overflying the township. Beware of crosswind and turbulence from trees. Gliding operations may be in progress any day, intensive on Thursday - Sunday and long weekends. Caution: tug planes may make contra rotating circuits. Rifle firing in progress is indicated by red flag on northern side runway 08. Soaring Club contacts: 0407 385361 (mobile), (08) 96460320 (airfield). Weather information: https://www.beverley-soaring.org.au . Cross check details with ERSA.		