


Warning: It is a requirement to check airstrip condition and details with owner prior to use

Janet Downs Station, QLD



NORTH TO THE TOP - DRAWING NOT TO SCALE

Elevation:	774 Feet AMSL	Time Zone:	UTC + 10
GPS Position:	24° 09.417' South 144° 04.205' East	Area Briefing:	41
WAC Chart:	Charleville (3341)	ALA Code:	YJNT
Owner/Operator:	Janet Downs Station (07) 46585323, laurendoug@bigpond.com		
Strip Directions:	18-36	10-28	
Strip Lengths:	700 M	500 M	
Strip Surface:	Unsealed - dirt		
Windsock:	Yes - but if not installed, there is a windmill at the dam on final runway 10		
Strip Markers:	Nil		
Lighting:	Nil		
Fuel:	Nil		
Procedures And Remarks:	CTAF 126.7. Brisbane Centre 122.1 (in the circuit). HF 3452/6610/8831. Beware power lines and trees at the western end. The runways are not joined, there is a gully between them. A local Drifter operates from this field. Mobile contact 0437 251964. Permission required prior to use, stock may need to be moved.		