


Warning: It is a requirement to check airstrip condition and details with owner prior to use

## Landers Creek Station, QLD



NORTH TO THE TOP - DRAWING NOT TO SCALE

<b>Elevation:</b>	135 Feet AMSL	<b>Time Zone:</b>	UTC + 10
<b>GPS Position:</b>	19° 58.533' South 147° 13.233' East	<b>Area Briefing:</b>	44
<b>WAC Chart:</b>	Townsville (3219)	<b>ALA Code:</b>	YLDC
<b>Owner/Operator:</b>	Bill and Stephanie Tudehope (07) 47849171, <a href="mailto:landerscreekpastoral@gmail.com">landerscreekpastoral@gmail.com</a>		
<b>Strip Directions:</b>	01-19		
<b>Strip Lengths:</b>	900 M		
<b>Strip Surface:</b>	Unsealed - dirt		
<b>Windsock:</b>	Yes		
<b>Strip Markers:</b>	Nil		
<b>Lighting:</b>	Nil		
<b>Fuel:</b>	Nil		
<b>Procedures And Remarks:</b>	CTAF 126.7. Brisbane Centre 120.55 (in the circuit). HF 3452/6610/8831. Mostly used by agricultural aircraft, dry weather only. Beware of trees, particularly at the northern end. Mobile contact: Bill 0427 958088 (no coverage at the house). Permission required prior to use.		