


Warning: It is a requirement to check airstrip condition and details with owner prior to use

# Netherway Station, NSW



<b>Elevation:</b>	473 Feet AMSL	<b>Time Zone:</b>	UTC + 10
<b>GPS Position:</b>	30° 41.000' South 148° 07.900' East	<b>Area Briefing:</b>	22
<b>WAC Charts:</b>	Bourke (3356), Armidale (3357)	<b>ALA Code:</b>	YNWY
<b>Owner/Operator:</b>	Netherway Station 0429 151433		
<b>Strip Directions:</b>	16-34		
<b>Strip Lengths:</b>	1300 M		
<b>Strip Surface:</b>	Unsealed - dirt		
<b>Windsock:</b>	Nil		
<b>Strip Markers:</b>	Nil		
<b>Lighting:</b>	Nil		
<b>Fuel:</b>	Nil		
<b>Procedures And Remarks:</b>	Beware animals. Caution, the runway is also a station road. This airstrip is available for use by the RFDS. Condition check and permission required prior to use, livestock will need to be moved.		