


Warning: It is a requirement to check airstrip condition and details with owner prior to use

Crab Claw Island, NT



Elevation:	33 Feet AMSL	Time Zone:	UTC + 9.5
GPS Position:	12° 42.794' South 130° 37.369' East	Area Briefing:	80
WAC Chart:	Darwin (3109)		
Owner/Operator:	Crab Claw Island Resort (08) 89782313, reservations@crabclaw.com.au		
Strip Directions:	16-34		
Strip Lengths:	830 M		
Strip Surface:	Unsealed - dirt		
Windsock:	Nil		
Strip Markers:	Nil		
Lighting:	Nil		
Fuel:	Nil		
Procedures And Remarks:	Brisbane Centre 118.15 (in the circuit). HF 3452/6541/8843. Beware of trees close to the runway. This airstrip is used by resort guests and for the occasional Aero Club fly in. It has good drainage but is not all weather. Latest information: manager John Roodenrys.		